



# STREET SCENE EQUIPMENT, INC.

**950-77128 SATIN FINISH**  
**&**  
**950-78128 CHROME FINISH**  
**GMC ENVOY**  
**2002**  
**SPEED GRILLE**  
**MAIN GRILLE**

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	4	Installation Clips # 71098
1	Got Street Scene Decal	1	Street Scene Emblem	2	Installation Clips # 71099
6	Black Washer Head Self Drilling Screws				

TOOL LIST	
Phillips Screwdriver	

1. Remove the grille shell from vehicle. Carefully pull from top to release the fasteners. Pull up from bottom to remove. Disconnect head lite washer hose.
2. Remove the GMC emblem from grille.
3. Install the GMC emblem to Speed Grille.
4. Insert the Speed Grille into the front side of grille shell making sure the bottom goes past the chrome ledge and into the black area below the verticle bar. The top will rest on the top of grille shell.
5. Fasten the bottom side using the 2 long clips to the center and the shorter clips on each side.
6. Fasten the top side with the six black self drilling screws.
7. Re-install grille into vehicle.
8. Install the Street Scene Emblem on grille face, Remove Protective cover.

**NOTE:** If you like you may cut out the horizontal bars in grille shell for a complete custom look.

