



STREET SCENE EQUIPMENT, INC.

950-77141 SATIN FINISH
&
950-78141 CHROME FINISH
CHEVY SILVERADO
& CHEVY HEAVY DUTY
[MAIN GRILLE](#)

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 45 minutes.

PARTS LIST					
1	Got Street Scene Decal	1	Instruction Sheet	1	Upper Speed Grille Section
1	Grille Care Instruction	1	Street Scene Emblem	1	Lower Speed Grille Section
6	Black Tie Straps			18	Installation Clips # 71092

TOOL LIST
Screwdriver / Side Cut Pliers

1. Open hood and remove the ABS cover between grille shell and core support.
2. Gently pull on the right and left corner of grille shell to release the fasteners, then gently pull the grille to the top and bottom of openings to release the other four " push in " fasteners. If you are unassure of this operation refer to GM service manual or have it done by a professional.
3. Install the Speed Grille inserts over the " X " members on the grille. From the back side clip the lower section using six of the 71092 clips across the bottom and six of the 71092 clips across the top. Install clips with the " humped " side toward the grille. The top section will be fastened in the same manner on the bottom side as the lower section. Fasten the top side of top Speed Grille by using the six black tie straps provided. Fasten at each end and equally spaced between. Loop the tie strap from the back side of grille through the " X " member and then through the loop on grille. Pull thigh. Cut off flush with back of grille.
4. Install the Street Scene Emblem to the lower right corner of the lower insert. Re move the protective cover.
5. Install Grille Shell back into vehicle.

