



STREET SCENE EQUIPMENT, INC.

950-77143 SATIN FINISH
&
950-78143 CHROME FINISH
CHEVY SILVERADO / GMC
& SIERRA
SSE VALANCE GRILLE
3 PC. SET

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

NOTE:

FITS STREET SCENE BUMPER COVER'S PART NUMBER'S 70143, 70144, 70165

PARTS LIST					
3 PC	Speed Grille Set	1	Instruction Sheet	10	Installation Clips # 71099
1	Street Scene Decal	1	Street Scene Emblem	8	Installation Clips # 71098
				1	Care For Grilles

TOOL LIST
NO TOOLS REQUIRED

NOTE:

We highly recommend installing Speed Grilles into valance before installing valance on vehicle.

1. Install Speed Grille inserts into their respective openings. From the backside, clip the side grilles using FOUR of the 71098 clips 3/4" long. Refer to illustration. Install the center Speed Grille into opening "clip" in the same manner using FIVE 71099 1" long clips on the top side and FIVE 71099 1" long clips on the bottom side.

Typical Clip Installation

