



STREET SCENE EQUIPMENT, INC.

950-77145 SATIN FINISH
 &
 950-78145 CHROME FINISH
SPEED GRILLE
 99 - 2001 SILVERADO, SUB,
 TAHOE
 OEM VALANCE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
2	Speed Grille Sections	1	Instruction Sheet	16	Attaching Clips # 71098
		1	Street Scene Emblem	1	Got Street Scene Decal

TOOL LIST
NONE

1. Remove Speed Grille sections from their packages. Each grille is marked for it's proper location and position.
2. Install Speed Grilles from the front side of valance and attach from the inside, with the clips provided. Position clips at each end, and to the right and left of the vertical bar. Make sure grille is installed fully into the opening.

