



STREET SCENE EQUIPMENT, INC.

950-76147 BLACK CHROME
950-77147 SATIN FINISH
950-78147 CHROME FINISH
950-79147 STAINLESS STEEL
2007
TAHOE / SUBURBAN /
AVALANCHE
[MAIN GRILLE INSERTS](#)

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

| PARTS LIST | | | | | |
|------------|---------------------|----------|---------------------|-----------|------------------------|
| 1 | Upper Grille Insert | 1 | Instruction Sheet | 16 | 11 " Ladder Tie Straps |
| 1 | Lower Grille Insert | 1 | Street Scene Emblem | 1 | Care For Grilles |

| TOOL LIST |
|---|
| 10 MM Socket, Extension, Ratchet, Side Cut Pliers |

1. Remove the six 10 MM head bolts across the top of the grille attaching it to the grille support panel. Four are located on the black top of grille and the other two are on the body colored vertical pieces on the grille.
2. Insert the bottom Speed Grille into the opening by slipping the top center in behind the " bow tie " and then inserting the entire Speed Grille.
3. Pull back the top of grille shell and reach behind and install four tie straps on the top and bottom on the Speed Grille. Insert the tie strap through the loop in Speed Grille and around the plastic bars on grille. Install tie straps to the outer ends and 4 - 6 inches from bow-tie. Install all tie straps before pulling tight. Cut off excess of ties with a pair of side cut pliers.
4. Install the upper Speed Grille insert in the same manner as the bottom Speed Grille section.