



STREET SCENE EQUIPMENT, INC.

950-77190 SATIN FINISH

950-78190 CHROME FINISH
H-2 HUMMER
7 PC. GRILLE SET

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Care For Grilles	1	Instruction Sheet	28	Installation Clips # 71098
		1	Street Scene Emblem	7 PC.	Speed Grille Inserts

TOOL LIST	
Simple Hand Tools	

NOTE: ALL PIECES ARE IDENTICAL

- Open hood. Reach in from behind turn signal lamps and remove the two nuts securing the chrome grille shell to fenders. Grasp the grille shell and gently pull to release the four "SNAP IN" fasteners located toward the center of grille.
Install the Speed Grille inserts into the seven openings with the tapered side of Speed Grille facing down. Fasten each insert using four clips two per side. Refer to illustration for reference.
- Install grille shell into vehicle.

TYPICAL CLIP INSTALLATION

