



## STREET SCENE EQUIPMENT, INC.

950-77370  
NISSAN XTERRA  
2000  
FACTORY  
BUMPER / VALANCE  
GRILLE

### INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 20 minutes

PARTS LIST					
1	Upper Grille Section	1	Instruction Sheet	16	Attaching Clips # 71098
1	Lower Grille Section	1	Street Scene Decal	1	Got Street Scene Decal

TOOL LIST	
Safety Glasses	

1. Before beginning installation be sure to wear proper eye protection.
2. Disconnect the air deflector from the bottom side of bumper.
3. Install the upper Speed Grille into the opening from the front side of vehicle. Attach from the back side with the attaching clips with the flat side facing away from the grille. Locate clips at each end top & bottom and to the inside of the vertical bars top & bottom.
4. Install the lower Speed Grille into the opening from the front side of vehicle. Attach from the back side with the attaching clips with the flat side facing away from the grille. Locate clips each ends top & bottom and to the inside of the vertical bars top & bottom.
5. Re-Attach the air deflector to the bumper.