



STREET SCENE EQUIPMENT, INC.

950-77507 SATIN FINISH
&
950-78507 CHROME FINISH
SPEED GRILLE
2002
DODGE RAM
MAIN GRILLE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Driver Side Upper	1	Instruction Sheet	24	Attaching Clips # 71093
1	Passenger Side Upper	1	Street Scene Emblem	1	Got Street Scene Decal
1	Driver Side Lower	1	Grille Care Sheet		
1	Passenger Side Lower				

TOOL LIST	
Miss. Tools	

1. Open hood and remove grille assemble from truck.
2. Set face down on a covered bench or table.
3. Remove metal frame work.
4. Remove the grey plastic grilles from shell by pushing a 1/8 round object into the center of retainer and push out center. Pry up on retainer and remove.
5. Install the Speed Grille insert from the front side. From the back side fasten using three clips across the top and three across the bottom. Install clip in center and at each end of Speed Grille. Do the same for all the inserts.
6. Re-install Grille Shell into the truck.
7. Install the Street Scene emblem to grille face. Remove the protective cover on it.

