



STREET SCENE EQUIPMENT, INC.

950-77509 SATIN FINISH
&
950-78509 CHROME FINISH
2002 - 2003
DODGE RAM
S/S VALANCE

INSTALLATION INSTRUCTIONS

NOTE: This Speed Grille insert fits Street Scene Bumper Cover Part # 950-70505 ONLY

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	RH Speed Grille Insert	1	Instruction Sheet	12	Installation Clips # 71098
1	LH Speed Grille Insert	1	Street Scene Emblem	1	Grille Care Instruction
				1	Got Street Scene Decal

TOOL LIST
No Tools Required

1. Install Speed Grille inserts into openings. Attach from back side using six clips per. Grille. Use three on Top and three on Bottom. Install clips with the humped side against the grille.
2. Install the Speed Grille emblem to grille face. Remove the protective covering.

