



# STREET SCENE EQUIPMENT, INC.

950-76514 BLACK CHROME  
 950-77514 SATIN FINISH  
 950-78514 CHROME FINISH  
 2006  
 DODGE RAM  
OEM VALANCE INSERT

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

**NOTE: WILL NOT FIT SPORT MODEL VEHICLES. USE Part # 77511 Or 78511**

**NOTE: WILL NOT WORK WITH TOW HOOKS**

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	14	Installation Clips # 71093
		1	Street Scene Emblem	1	Speed Grille Care

TOOL LIST
#2 Phillips Screwdriver, Flat Blade Screwdriver

1. Remove the ABS filler in bumper if equipped by removing the four phillips screws facing upward, Carefully pry out the black housing. Save fasteners.
2. Open hood. Reach in behind bumper and unsnap the bottom side of filler piece. Re-install the fasteners to bumper. NOTE: If screws will not unscrew apply pressure to the top side of screw ( in the inside of bumper ) while unscrewing.
3. Install the Speed Grille into the opening. Clip from the back side using seven clips across the top and seven across the bottom. Refer to photo for installation.

### TYPICAL CLIP INSTALLATION

