



STREET SCENE EQUIPMENT, INC.

INSTALLATION INSTRUCTIONS

950-77560 SATIN FINISH
&
950-78560 CHROME FINISH
CHEVY SILVERADO
SUBURBAN & TAHOE
MAIN GRILLE WITH SHELL
& WITH NO BOW TIE

NOTE: Grille Must Be Color Matched To Vehicle. TEST Fit BEFORE Painting A Small Amount Of Grinding And Sanding Will Be Necessary For A Good Fitment.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Upper Speed Grille	1	Instruction Sheet	28	Installation Clips # 71098
1	Lower Speed Grille	1	Grille Shell	1	Care For Grilles Sheet
1	Got Street Scene Decal	1	Street Scene Emblem	4	1" OD Flat Washers
4	6 MM Body Bolts	4	6 MM Nuts		

TOOL LIST
Phillips Screwdriver, Flat Blade Screwdriver, Drill Motor, 1/4" Drill Bit, 10 MM Wrench, 10 MM Socket, Ratchet, Extension

1. Remove factory grille from truck. Open the hood and remove the seven retaining clips the secure the air deflection panel to the grille shell. Remove the fastener at the right of grille center. Using a phillips head screwdriver, turn the four grille screws securing fastener located just inward of the headlight and parking lights, 1/4 turn counter clockwise. Grasp the grille shell at each end and pull gently to release the retaining fasteners. At the points where the securing fasteners were unlocked, gently pull out and remove grille shell.
2. Remove all attaching hardware.
3. Remove the four plastic quick connect fasteners from core support.
4. Set the grille shell up to the core support. Mark the location of the four fastening points (position where the quick connect fasteners were removed). Drill a 1/4" hole at each of these locations. Install the metal fasteners at each end of grille shell.
5. Color match grille to vehicle.
6. Install the Speed Grille inserts into their respective openings. Attach from the back side using 7 clips across the top and 7 clips across the bottom.
7. Install grille shell into vehicle. Use the four 6 MM body bolts provided. Use the one inch OD washer over bolt and the 10 MM head nut provided.
8. Install the Street Scene Emblem on the grille face. Remove the protective cover.

