



STREET SCENE EQUIPMENT, INC.

950-77603
SPEED GRILLE INSERT
1997-UP DODGE DAKOTA
& DURANGO
FRONT VALANCE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 10 To 15 minutes.

PARTS LIST					
2	Speed Grille Section	1	Instruction Sheet	8	Attaching Clips # 71098
		1	Street Scene Decal	1	Got Street Scene Decal

TOOL LIST	
NO TOOLS NEEDED	

1. Before beginning installation be sure to wear proper eye protection.
2. Remove Speed Grille sections from their packages. Each Speed Grille section is labeled for it's location and top side.
3. Install the Speed Grille sections one at a time from the front of valance, then secure each section with four clips installed from the back of valance. Attach two clips evenly spaced on the bottom and two on the top of each section.