



# STREET SCENE EQUIPMENT, INC.

**950-77620 SATIN FINISH**  
**950-78620 CHROME FINISH**  
**2006 - 2007**  
**DODGE CHARGER**  
[SPEED GRILLE INSERTS](#)

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
<b>4 PC Set</b>	Speed Grille Inserts	<b>1</b>	Instruction Sheet	<b>24</b>	Installation Clips # 71098
		<b>1</b>	Street Scene Emblem	<b>1</b>	Care For Grilles

TOOL LIST	
Flat Blade Screwdriver	

1. Remove obstructions to gain access to back side of grille.
2. Remove the Black plastic backing by unsnapping it.
3. Install the Speed Grille sections one at a time into their respective openings. Clip from the back side using six clips per grille. Install three clips on the top side and three on the bottom side of each grille. Do the same on all Speed Grille inserts.

### TYPICAL CLIPPING PROCEDURE

