



# STREET SCENE EQUIPMENT, INC.

**950-77661**  
**2004**  
**VOLVO S60 / V70**  
**SPEED GRILLE INSERT**  
**VALANCE GRILLE**

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

**NOTE: It will be necessary to remove the front facia to install Speed Grille**

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	4	Installation Clips # 71099
1	Care For Grilles	1	Street Scene Emblem	4	Push In Fasteners

TOOL LIST	
12 MM Socket, 8 MM Socket, Ratchet, Extension, Drill Motor, 1/4" Drill Bit	

1. Remove the headlight wipers by flipping up the cap and removing the 8 MM nut securing it.
2. Remove the fasteners located in the lower corners of the right and left wheel wells.
3. Open hood. Remove the six fasteners across the top side of facia. To do this push the center in and pry out the fastener. Save all fasteners for re-assemble.
4. Remove the black impac strips.
5. Remove the two 12 MM head bolts that are now exposed.
6. Un-snap facia at the wheel well ends and remove.
7. Set on table or bench.
8. Remove the rubber strip across top of opening.
9. Install the Speed Grille into opening. Fasten the top side using four 71099 clips and the bottom side using the four push in fasteners drill four 1/4" holes thru the loop in Speed Grille and into facia. Insert push in fasteners.
10. Install front facia in reverse order of removal.

### TYPICAL CLIP INSTALLATION

