

STREET SCENE EQUIPMENT, INC.

950-77706
2001
FORD ESCAPE
SPEED GRILLE MAIN
GRILLE INSERT

INSTALLATION INSTRUCTIONS

VERY IMPORTANT! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 2 hours.

| PARTS LIST | | | | | |
|------------|------------------------|---|---------------------|----|----------------------------|
| 1 | Speed Grille Section | 1 | Instruction Sheet | 10 | Installation Clips # 71098 |
| 1 | Got Street Scene Decal | 1 | Street Scene Emblem | | |

TOOL LIST Miss. Hand Tools, Cutting Device IE (Power Hack Saw, Die Grinder, Coping Saw Or hack Saw Blade)

Sand paper, Black Spray paint.

- 1. Remove the front grille shell assemble from the vehicle.
- 2. Set the grille shell on a protective covered table or bench.
- 3. Using a cutting device, cut out the center leaving only the perimeter.
- 4. Sand all cuts and paint with a satin black paint.
- **5.** Install the Speed Grille insert into the opening and clip from the back side with th clips provided. Use five clips on the top and five on the lower.
- **6.** Re-install grille shell into the vehicle.
- 7. Install the "Street Scene Emblem" on the grille. Remove the protective cover.