



**STREET SCENE EQUIPMENT, INC.**

**950-77709**  
**FORD ESCAPE**  
**2001**  
**OEM BUMPER COVER**  
**SPEED GRILLE**

**INSTALLATION INSTRUCTIONS**

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 30 TO 40 minutes.

<b>PARTS LIST</b>					
<b>1</b>	Got Street Scene Decal	<b>1</b>	Instruction Sheet	<b>1</b>	Upper Speed Grille Insert
		<b>1</b>	Street Scene Emblem	<b>1</b>	Lower Speed Grille Insert
				<b>16</b>	Installation Clips # 71098

<b>TOOL LIST</b>	
Simple Hand Tools	

1. Remove any air deflector shields beneath the front bumper to gain access to back side of bumper cover.
2. Remove Speed Grille inserts from their packages and install into their openings from the front side of opening.
3. Slide the clips over the valance edge and over the return edge of grille, with th flat side facing away from the grille.
4. Attach the " Speed Grille Emblem " to the grille face. Remove the protective cover.
5. Re-install air deflector if removed.