



STREET SCENE EQUIPMENT, INC.

950-77737
2002
FORD EXPLORER
OEM BUMPER / VALANCE
SPEED GRILLE INSERT

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 15 minutes.

PARTS LIST					
3 PC.	Speed Grille Sections	1	Instruction Sheet	12	Installation Clips # 71098
1	Got Street Scene Decal	1	Street Scene Emblem	1	Street Scene Decal

TOOL LIST	
NO TOOLS REQUIRED	

1. Raise front of vehicle to gain access to the back side of bumper / valance openings.
2. Install the Speed Grille inserts from the front side of bumper cover. Clip from the back side using four clips per grille section. Use two on the top side and two on the lower side.
3. Install the Street Scene Emblem on the grille face and remove it's protective cover.

NOTE:

If any air deflectors are located between the bumper and core support remove them to gain access. Make sure you re-install them when done.