



STREET SCENE EQUIPMENT, INC.

950-77755
2001
FORD EXPLORER OEM
VALANCE
SPEED GRILLE INSERT

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 15 minutes.

PARTS LIST					
1	Speed Grille Section	1	Instruction Sheet	10	Installation Clips # 71099
1	Got Street Scene Decal	1	Street Scene Emblem		

TOOL LIST	
NO TOOLS REQUIRED	

1. Install the Speed Grille insert into the opening in valance from the front side of vehicle.
2. Attach from the back side by sliding the clip over the valance return ledge over the Speed Grille with the " Humped " side of clip on the grille. Install clips at each outer end, at center of grille, and evenly spaced between. Do the same on the top and bottom sides.
3. Install the S/S emblem to the grille face. Remove the protective cover on it.