



STREET SCENE EQUIPMENT, INC.

950-76765 BLACK CHROME
 &
 950-77765 SATIN FINISH
 2005
 950-78765 CHROME FINISH
 2005
 FORD F-350 SUPER DUTY
OEM BUMPER SPEED
GRILLE INSERT

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	8	Installation Clips # 71098
		1	Street Scene Emblem	1	Care For Grilles

TOOL LIST

1. Install the Speed Grille insert into the opening. Fasten from the back side using the clips provided. Refer to the illustration for clipping procedure. You may reach up from the bottom side to clip or simply just remove the grille shell to gain easy access. (Recommended)
2. Install four clips across the top and four along the bottom side.

TYPICAL CLIP INSTALLATION

