



STREET SCENE EQUIPMENT, INC.

950-77807
SPEED GRILLE
1999 - 2000
FORD EXPEDITION
WITH STREET SCENE
950-70807 BUMPER COVER &
VALANCE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions, then check the following parts list before starting installation.

| PARTS LIST | | | | | |
|------------|---------------------|---|--------------------|---|-------------------------|
| 1 | Speed Grille Insert | 1 | Instruction Sheet | 8 | Attaching Clips # 71098 |
| | | 1 | Street Scene Decal | | |

| TOOL LIST | |
|-----------|--|
| NONE | |

1. Insert Speed Grille into front valance from the front side of valance. Make sure Speed Grille is positioned properly.
2. Attach from the back side using the clips provided with the flat side facing away from the grille. Clip at each end top and bottom and center the remaining clips between.

TYPICAL CLIP INSTALLATION

