



STREET SCENE EQUIPMENT, INC.

**950-77812 Satin Finish
&
950-78812 Chrome Finish
Valance Insert**

INSTALLATION INSTRUCTIONS

NOTE: THIS GRILLE INSERT FITS THE 950-70811 STREET SCENE VALANCE ONLY

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	5	Installation Clips # 71099
1	Care For Grille Sheet	1	Street Scene Emblem	4	#8 X 3/4" Washer Head Screw
1	Got Street Scene Decal				

TOOL LIST
Phillips Screwdriver

1. Install the Speed Grille insert into the Bumper Cover / Valance assemble before installing on vehicle.
2. Install grille into Bumper Cover from the front side. From the rear use the five clips and clip Speed Grille at center, each end, and in between.
3. Use the screws provided and screw through the holes in the Speed Grille and into the Bumper Cover.
4. Install the Street Scene Emblem on the grille face. Remove the protective cover.

