STREET SCENE EQUIPMENT, INC.



950-77813 FORD RANGER

2001 - 2002 MAIN GRILLE

4WD & EDGE MODELS

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 40 minutes.

PARTS LIST						
1	Speed Grille Section	1	Instruction Sheet	6	Installation Clips # 71098	
1	Got Street Scene Decal	1	Street Scene Emblem	6	Self drilling Phillips Head Screws	
				1	Care For Grille Instruction	

TOOL LIST	
Phillips Screwdriver	

- **1.** Remove the Grille Shell from the truck.
- 2. Remove the six attaching fasteners accross the top side of grille shell.
- **3.** Release the six " Push In " retainers securing the grille shell by gently pulling the bottom of the grille shell outward, Two fasteners are located below the grille opening and two are located below the headlite capsules on each side.
- 4. Insert the Speed Grille over the honey comb area of the grille.
- 5. Secure the bottom side by sliding the attaching clips from the back side of grille shell over the plastic ledge and onto the return edge of Speed Grille. Space clips evenly across the bottom.
- 6. Push the top side inward and secure with the screws provided. Space screws evenly across the top.
- 7. Re-install grille shell into vehicle.
- 8. Install the Street Scene Emblem to grille face. Remove the protective cover.
- **NOTE:** If the metal retainers are still in the body they, they must be removed and installed on grille shell before installing grille shell.