



STREET SCENE EQUIPMENT, INC.

950-77817
2001 - 2002
FORD RANGER
OEM BUMPER COVER
GRILLE INSERT

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 15 minutes.

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	4	Installation Clips # 71098
1	Got Street Scene Decal	1	Street Scene Emblem	4	Installation Clips # 71095
				1	Speed Grille Care

TOOL LIST	
NO TOOLS REQUIRED	

1. Insert the Speed Grille insert into the opening in bumper cover.
2. Attach from the back side using the four shorter clips on the top side and the four longer clips on the bottom side.
3. Install the Street Scene Emblem on the grille face. Remove the protective cover.