



STREET SCENE EQUIPMENT, INC.

950-77835
2001
FORD SPORT TRACK
GRILLE INSERTS
OEM VALANCE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation. Installation time is approximately 20 minutes.

PARTS LIST					
1	Street Scene Emblem	1	Instruction Sheet	12	Installation Clips # 71098
1	Got Street Scene Decal			1	L.H. Speed Grille Section
1	R.H. Speed Grille Section			1	Center Speed Grille Section

TOOL LIST	
No Tools Necessary	

1. Install the Speed Grille inserts into the openings in the valance. Clip from the back side using four clips per section. **NOTE:** Flat side of clip goes away from grille insert.
2. Install Street Scene Emblem to the grille face. Remove the protective cover on it.