



STREET SCENE EQUIPMENT, INC.

950-77113 SATIN FINISH
&
950-78113 CHROME FINISH
SPEED GRILLE INSERT
1999 CHEV SILVERADO
WITH STREET SCENE
950-70113 VALANCE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	RH Grille Section	1	Instruction Sheet	8	Attaching Clips # 71098
1	LH Grille Section	1	Street Scene Decal	1	Got Street Scene Decal

TOOL LIST	
NO TOOLS NEEDED	

note: If you are installing Street Scene 950-70113 valance, install grille inserts into valance prior to installing valance.

1. Remove Speed Grille sections from their packages. Each grille is marked for it's proper location and position.
2. Install the Speed Grilles from the front side of valance. Attach each Speed Grille section with a clip at each bottom end, and at each top outer and at the top center. Install clips so that the flat side of clip is facing away from grille.

