



# STREET SCENE EQUIPMENT, INC.

950-76126 BLACK CHROME  
 950-77126 SATIN FINISH  
 950-78126 CHROME FINISH  
 950-79126 STAINLESS STEEL  
 2002 - 2006  
[CHEVY TRAIL BLAZER](#)

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Upper Speed Grille	1	Instruction Sheet	12	3/4" Long Attaching Clips # 71098
1	Lower Speed Grille	1	Care For Grilles Sheet		
6	11" Ladder Ties				

TOOL LIST	
Side Cut Pliers	

1. Remove grille shell from vehicle by " un-snapping " the fasteners from front end, fasteners are located at each end of center strip, four across the top and two at the bottom. Gently pull on grille shell to release.
2. Insert the bottom grille section into grille shell. The Speed Grille will go over the bottom ledge of shell. Attach grille using the 71098 clips, Use six on the bottom and six on the top. Humped side of clip goes against Speed Grille.
3. The bottom side of speed grille will be attached by using the cable ties provided. Loop the cable tie through the " loop " in Speed Grille and around the X bars in the grille shell. Install all cable ties before pulling tight cut off excess.
4. Re-install grille shell into vehicle.

### TYPICAL CLIP INSTALLATION

