STREET SCENE EQUIPMENT,INC.

950-76133 BLACK CHROME
950-77133 SATIN FINISH
950-78133 CHROME FINISH
2006 - 2008
CHEVY TRAIL BLAZER
SPEED GRILLE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Upper Speed Grille	**1**	Instruction Sheet	**16**	Ladder Ties
1	Lower Speed Grille	**1**	Stree Scene Emblem	**1**	Care For Grilles

TOOL LIST
Side Cut Pliers

1. Remove the grille shell from the vehicle by pulling forward to release the metal clips on the back side.

2. The Speed Grille inserts are designed to lay atop of the grids on grille shell. DO NOT cut out. The Speed Grilles are attached by using eight ladder ties per grille section. Use four ties on the top side and four on the bottom side of each grille.

3. Insert the grille tie through the loop on the Speed Grille and around the grid on the grille. Install all ties loosely, then position grille and pull tight. Cut off excess.

4. Do the same on both Speed Grille inserts. Position grille ties at each and and equally space the other two between.

5. Install grille shell back into vehicle. Snap into position.