



STREET SCENE EQUIPMENT, INC.

INSTALLATION INSTRUCTIONS

950-77138 SATIN FINISH
&
950-78138 CHROME FINISH
1999 - 2002
CHEVY SLIVERADO
2000 - 2006
CHEV SUBURBAN / TAHOE
SPEED GRILLE INSERT

NOTE: This Speed Grille insert fits Street Scene Valance Part # 950-70138 ONLY

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	6	Installation Clips # 71098
		1	Street Scene Emblem	6	Installation Clips # 71099
				1	Care For Grilles Sheet

TOOL LIST
No Tools Required

1. Install the Speed Grille insert into the opening in valance.
2. From the backside attach using the clips provided. Use six of the shorter clips across the top and six of longer clips across the bottom.
3. Install the Speed Grille Emblem onto the Speed Grille face. Remove the protective cover.

TYPICAL CLIP INSTALLATION

