



# STREET SCENE EQUIPMENT, INC.

**950-77143 SATIN FINISH**  
**&**  
**950-78143 CHROME FINISH**  
**CHEVY SILVERADO / GMC**  
**& SIERRA**  
[SSE VALANCE GRILLE](#)  
[3 PC. SET](#)

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

### NOTE:

**FITS STREET SCENE BUMPER COVER'S PART NUMBER'S 70143, 70144, 70165**

PARTS LIST					
<b>3 PC</b>	Speed Grille Set	<b>1</b>	Instruction Sheet	<b>10</b>	Installation Clips # 71099
<b>1</b>	Street Scene Decal	<b>1</b>	Street Scene Emblem	<b>8</b>	Installation Clips # 71098
				<b>1</b>	Care For Grilles

TOOL LIST
NO TOOLS REQUIRED

### NOTE:

We highly recommend installing Speed Grilles into valance before installing valance on vehicle.

1. Install Speed Grille inserts into their respective openings. From the backside, clip the side grilles using **FOUR** of the 71098 clips 3/4" long. Refer to illustration. Install the center Speed Grille into opening "clip" in the same manner using **FIVE** 71099 1" long clips on the top side and **FIVE** 71099 1" long clips on the bottom side.

### Typical Clip Installation

