



# STREET SCENE EQUIPMENT, INC.

**950-77146 SATIN FINISH**  
**&**  
**950-78146 CHROME FINISH**  
**2003**  
**CHEVY SILVERADO**  
**OEM VALANCE**  
**SPEED GRILLE INSERT**

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
<b>2 PC.</b>	Speed Grille Set	<b>1</b>	Instruction Sheet	<b>8</b>	Installation Clips # 71099
<b>1</b>	Street Scene Decal	<b>1</b>	Street Scene Emblem	<b>1</b>	Care For Grilles

TOOL LIST	
NO TOOLS REQUIRED	

1. Install the Speed Grille into their openings in valance. Each Speed Grille is labeled for it's location. Refer to illustration and " clip " Speed Grille into valance using two clips on the bottom side and two clips on the top side.

### Typical Clip Installation

