



STREET SCENE EQUIPMENT, INC.

950-76148 BLACK CHROME
950-77148 SATIN FINISH
950-78148 CHROME FINISH
2007 - 2008
CHEVY SUBURBAN / TAHOE
AVALANCHE
[OEM VALANCE GRILLE](#)

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

TOW HOOKS MUST BE REMOVED

PARTS LIST					
1	RT Speed Grille Insert	1	Instruction Sheet	8	Installation Clips # 71098
1	LT Speed Grille Insert	1	Street Scene Emblem	1	Care For Grilles

TOOL LIST	
NONE REQUIRED	

1. Remove the black plastic tow hook fillers from openings by unsnapping the six retainers.
2. Install the Speed Grille insert into opening check for proper grille for opening.
3. Secure from the back side using four clips. Slide the clip over the valance edge and onto Speed Grille. Use two clips on the top side and bottom side.

TYPICAL CLIP INSTALLATION

