



# STREET SCENE EQUIPMENT, INC.

950-77152 SATIN FINISH  
 &  
 950-78152 CHROME FINISH  
 2002 - 2005  
 CHEVY TRAILBLAZER  
 S/S VALANCE  
SPEED GRILLE INSERT

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

**NOTE:** This Speed Grille fits Street Scene valance Part Number 950-70152 ONLY  
 Use part number 950-77131 for factory bumper cover / valance.

PARTS LIST					
1	Upper Grille Section	1	Instruction Sheet	12	Installation Clips # 71098
1	Lower Grille Section	1	Street Scene Emblem	6	Installation Clips # 71097
				6	Washer Head Self Drilling Screws

TOOL LIST	
1/2" Drill Bit, Drill Motor, Phillips Head Screwdriver	

### SPECIAL NOTE:

**we highly recommend installing the Speed Grille inserts into Valance before installing Valance on vehicle.**

1. Set lower Speed Grille insert into lower opening of valance. Take note of where grille contacts valance. It will be necessary to drill a 1/2" hole as close to the edge as possible at six points across the top and six points across the bottom to install the installation clips.

### REFER TO ILLUSTRATION

2. Install the top Speed Grille into the opening. Attach the bottom side using the six short clips. Attach the top side by installing a screw through the grille opening and into valance. Use six screws on this operation.
3. Install the Speed Grille Emblem on grille face. Remove the protective cover.

