



STREET SCENE EQUIPMENT, INC.

950-77187 SATIN FINISH
950-78187 CHROME FINISH
2006 - 2007
ISUZU i290 / i370
SPEED GRILLE INSERTS

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

| PARTS LIST | | | | | |
|--------------|-------------------------|----------|---------------------|-----------|----------------------------|
| 6 PC. | Speed Grille Insert Set | 1 | Instruction Sheet | 28 | Installation Clips # 71098 |
| | | 1 | Street Scene Emblem | 1 | Care For Grilles |

| TOOL LIST |
|--|
| No Tools Needed But Flat Blade Screwdriver Helpful |

1. Open hood and unplug the parking lamps at the top corners of grille.
2. Remove grille shell from vehicle by grasping the shell and pulling to release the fasteners. NOTE: there are no screws securing the grille shell.
3. Set the grille shell on a protective covered bench or table.
4. Remove Speed Grille inserts from packages
5. Install Speed Grille inserts one at a time into openings and " Clip " into position. The longer of the two center grilles goes on the top opening. The grilles fit over the grey ledge in the grates. Clip the center grilles using two clips on the top and two on the bottom side. The Right and Left side grilles use three clips each. Clip to grille shell at longest loop of Speed Grille. Refer to drawing below for clipping procedure. It is OK to squeeze the Speed Grille a little when installing.
6. Install grille shell back into truck. Make sure all fasteners points are fastened. NOTE: the mounting points at lower right & left of center of grille are very thin. DO NOT use excess force, or the mounting points will bend. If they do they can be straighten with minimal effort.

TYPICAL CLIP INSTALLATION

