



STREET SCENE EQUIPMENT, INC.

950-77200 SATIN FINISH
 &
 950-78200 CHROME FINISH
SPEED GRILLE
 94-97 CHEVY "S" SERIES
 W / FLUSH HEADLIGHTS
 MAIN GRILLE

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
2	Speed Grille Sections	1	Instruction Sheet	16	Attaching Clips # 71098
		1	Street Scene Emblem	1	Got Street Scene Decal

TOOL LIST
3/8" drive ratchet, 3/8" drive 6" extension, 3/8" drive 7 MM socket, safety glasses

NOTE:
Top And bottom grilles are the same.

1. Before beginning installation be sure to wear proper eye protection.
2. Open the hood. Remove the four 7mm screws fastening the grille at the top. Remove the two remaining 7mm screws in the center of the grille above and below the "Bowtie".
3. Gently pull grille from the bottom to release the clips attaching it to the core support. (Be careful not to scratch the bumper when removing). Tip: Lay masking tape over the top surface of the bumper.
4. Set grille on a soft, covered, clean work bench or table.
5. Remove the "Speed Grille" from their packages. **NOTE:** Top and bottom grilles are the same.
6. Place the "Speed Grille" in the upper opening of the grille shell with the Bowtie recess facing down. Using eight of the clips provided, clip "Speed Grille" in from the backside of grille shell with the flat side of clip facing away from grille. Locate clips at two inches from each end, top and bottom and center the others equally across. Make sure the "Speed Grille" is securely fastened.
7. Repeat this process for the lower section. Except the Bowtie recess will be facing up.
8. Install grille assembly by first snapping the bottom into the core support and then attaching the six 7mm screws that were removed in step two.

