



STREET SCENE EQUIPMENT, INC.

950-77245 SATIN FINISH
&
950-78245 CHROME FINISH
2004
CHEVY COLORADO
GENERATION 2
BUMPER COVER
S/S DESIGN SPEED GRILLE
INSERTS

INSTALLATION INSTRUCTIONS

NOTE:

This Speed Grille Set Fits P.N. 950-70218 ONLY

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Care For Grilles	1	Instruction Sheet	1	Center Speed Grille Insert
		1	Street Scene Emblem	1	RH Speed Grille Insert
				1	LH Speed Grille Insert
4	Installation Clips # 71099 1" Long			12	Installation Clips # 71098 3/4" Long

TOOL LIST
None

NOTE:

We recommend installing Speed Grille inserts prior to installing bumper cover.

1. Insert the center Speed Grille into opening. Clip from back side using four 71098 clips across the top and four 71099 clips across the bottom. Refer to illustration for clipping procedure.
2. Install the side grilles into there openings. " Clip " using two clips on top and bottom side **NOTE:** Side Speed Grilles are marked for there location.

TYPICAL CLIP INSTALLATION

