



# STREET SCENE EQUIPMENT, INC.

**950-77509 SATIN FINISH**  
 &  
**950-78509 CHROME FINISH**  
 2002 - 2003  
DODGE RAM  
S/S VALANCE

## INSTALLATION INSTRUCTIONS

**NOTE:** This Speed Grille insert fits Street Scene Bumper Cover Part # 950-70505 ONLY

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

| PARTS LIST |                        |   |                     |    |                            |
|------------|------------------------|---|---------------------|----|----------------------------|
| 1          | RH Speed Grille Insert | 1 | Instruction Sheet   | 12 | Installation Clips # 71098 |
| 1          | LH Speed Grille Insert | 1 | Street Scene Emblem | 1  | Grille Care Instruction    |
|            |                        |   |                     | 1  | Got Street Scene Decal     |

| TOOL LIST         |
|-------------------|
| No Tools Required |

1. Install Speed Grille inserts into openings. Attach from back side using six clips per. Grille. Use three on Top and three on Bottom. Install clips with the humped side against the grille.
2. Install the Speed Grille emblem to grille face. Remove the protective covering.

