



# STREET SCENE EQUIPMENT, INC.

950-76523 BLACK CHROME  
 950-77523 SATIN FINISH  
 950-78523 CHROME FINISH  
 2009  
 DODGE RAM  
[MAIN SPEED GRILLE INSERTS](#)

## INSTALLATION INSTRUCTIONS

**VERY IMPORTANT !** Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
<b>4 PC</b>	Speed Grille Insert Set	1	Instruction Sheet	24	Installation Straps ( 11" Long )
		1	Street Scene Emblem		

TOOL LIST
Side Cut Pliers

1. Open hood.
2. Open Speed Grille insert packages. Set Speed Grilles on a table or bench and identify for location.
3. It is not necessary to remove the grille shell from the vehicle to install the Speed Grille. The Speed Grille inserts will be attached to grille shell the installation straps. Use six straps per one grille section. Loop the strap through the loop on the Speed Grille and then around the horizontal bar on grille shell. Install all straps loosely and snug up equally, centering the Speed Grille in opening. There should be an 1/8" to 3/16" clearance gap on all sides. After you are sure of the placement of Speed Grille, Pull all straps snug and cut off the excess. Do the same on all the grille sections. Cut off excess plastic from straps.