



STREET SCENE EQUIPMENT, INC.

INSTALLATION INSTRUCTIONS

950-74592 BLACK POWDER
COAT PAINT
&
950-76592 BLACK CHROME
&
950-77592 SATIN FINISH
&
950-78592 CHROME FINISH
2005 - 2006
FORD MUSTANG 6 CYL
COBRA STYLE GRILLE KIT

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Street Scene Grille With Inserts			8	Phillips Head Screws # 66126
1	Street Scene Emblem	1	Instruction Sheet	2	Light Harness Extensions
1	Care For Grilles				

TOOL LIST	
Flat Blade Screwdriver, Drill Motor, 1/8" Drill Bit, Phillips Head Screwdriver	

NOTE:

Use Ford driving lights P.N. 4R37-15200-AA and P.N. 4R37-15200-AB These can be purchased at your Local Ford Dealer

NOTE:

Use Street Scene wire harness kit P.N. 950-73591 Kit is complete with everything you need for a factory look installation.

1. Open hood. Pry out the push in fasteners across the panel over the grille. To remove fasteners pry up the center pin using a flat blade screwdriver and then pry the body out. Remove panel. Save fasteners.
2. To remove grille use a long flat blade screwdriver and depress the two tabs on each side of the grille in the front fascia. Pull the grille forward and depress the five tabs along the bottom in the same manner. Remove grille.
3. Drill an 1/8" diameter hole into each of the eight light mounting bosses on the grille. Install the lamps with the phillips head screws provided. Tighten securely DO NOT OVER TIGHTEN. You can strip out the holes. It may be necessary to move the boss on grille shell to align with the hole in lamps.
4. Install the wire harness extension to each lamp.
5. Install the wire harness to vehicle (sold separately) at this time. Follow the instructions included with the wire harness kit.
6. Connect lamps to harness and snap grille into fascia. DO NOT push on grille face. Apply the pressure to the black grille shell.
7. Adjust lamps to OEM specifications.
8. Install the top panel removed in step one.