



STREET SCENE EQUIPMENT, INC.

950-77620 SATIN FINISH
950-78620 CHROME FINISH
2006 - 2007
DODGE CHARGER
SPEED GRILLE INSERTS

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
4 PC Set	Speed Grille Inserts	1	Instruction Sheet	24	Installation Clips # 71098
		1	Street Scene Emblem	1	Care For Grilles

TOOL LIST	
Flat Blade Screwdriver	

1. Remove obstructions to gain access to back side of grille.
2. Remove the Black plastic backing by unsnapping it.
3. Install the Speed Grille sections one at a time into their respective openings. Clip from the back side using six clips per grille. Install three clips on the top side and three on the bottom side of each grille. Do the same on all Speed Grille inserts.

TYPICAL CLIPPING PROCEDURE

