



STREET SCENE EQUIPMENT, INC.

950-76696 BLACK CHROME
 950-77696 SATIN FINISH
 950-78696 CHROME FINISH
 2007 - 2008
 FORD FOCUS
BUMPER COVER
SPEED GRILLE INSERTS
3 PC SET

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST			
1	RH Speed Grille Insert	1	Instruction Sheet
1	LH Speed Grille Insert	6	Installation Clips # 71092
1	Center Speed Grille Insert	1	Care For Grilles
6	11" Cable Ties	1	Street Scene Emblem

TOOL LIST
SM Metric Scket Set, Flat Blade Screwdriver, Side Cut Pliers

1. Raise the front of vehicle to gain access to the back side of bumper openings.
2. Remove the ABS apron, by removing all fasteners securing it to bumper cover and underside of vehicle. You will find " push In " fasteners and hex headed screws.
3. Insert the center Speed Grille into the center opening the top side will be fastened to the black plastic grids using two cable ties. Insert the cable tie through the loop in the Speed Grille and then through the X member in the plastic grid. Install the cable ties approximately 1" from each end. The bottom side of the Speed Grille will be fastened using two of the metal clips provided. Install the clips with the " humped " side up. The clip will go through the X grids and onto the Speed Grille. Clip as close to each end as possible.
4. The side Speed Grilles are installed in the same manner. Except due to the side air deflectors behind grids you will not be able to install the cable ties and steel clips on the outside ends. They will have to be installed inboard apporximatley 5" from the ends.
5. Pull all cable ties snug and cut off excess.
6. Re-install ABS apron removed in step 2.