



STREET SCENE EQUIPMENT, INC.

950-77725 SATIN FINISH
 &
 950-78725 CHROME FINISH
SPEED GRILLE
 1999-2002 FORD
 EXPED / F-150 W / OEM
 FRONT VALANCE

INSTALLATION INSTRUCTIONS

NOTE :

Valance insert for 1999 Ford EXPED / F-150 W / OEM front valance W / Or W / O fog lamps & tow hooks
 (will not fit Base Model F-150) ALSO : No drilling Required.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST

4	Speed Grille Sections	1	Instruction Sheet	16	Attaching Clips # 71098
		1	Street Scene Emblem	1	Got Street Scene Decal

TOOL LIST

Safety glasses

- 1 . Before beginning installation be sure to wear proper eye protection.
- 2 . Remove Speed Grille sections from their packages. Each Speed Grille section is labeled for it's location and top side.
- 3 . Install the Speed Grille sections into their location of valance from the front side.
- 4 . Attach from backside with 4 attaching clips per section. Two on top and two on the bottom.
- 5 . Make sure Speed Grille sections are positioned properly and that the barbs on the clips are locked into the holes in the Speed Grille.

