



STREET SCENE EQUIPMENT, INC.

950-76766 BLACK CHROME
 950-77766 SATIN FINISH
 950-78766 CHROME FINISH
 950-79766 STAINLESS STEEL
 2008
 FORD SUPER DUTY

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST			
1	Upper Speed Grille Insert	1	Instruction Sheet
1	Lower Speed Grille Insert	1	Street Scene Emblem
1	Center RT Speed Grille Insert	40	Installation Clips # 71099
1	Center LT Speed Grille Insert	1	Care For Grilles
1	RT Side Speed Grille Insert	8	11" Ladder Tie Strap
1	LT Side Speed Grille Insert		

TOOL LIST
Phillips Screwdriver, 11 MM Socket, Extension, Ratchet

1. Remove all Speed Grille inserts from packages, Each grille is marked for it's proper location.
 2. Open hood. Remove the seven black plastic fasteners securing the grille shell to hood, located on the top side of the top horizontal and side openings. This can be achieved by first backing out the center phillips head screw and then prying out the body.
 3. Remove the two 11 MM bolts at the outer ends of the bottom of grille shell securing the grille shell to the metal structure.
 4. Lift gently and unsnap the top of grille shell to hood.
 5. Insert the Speed Grille into their respective openings. Clip from the back side using the installation clips provided.
 6. Use eight clips for the upper and lower grilles. Four on the top and four on the bottom side.
- NOTE:** The side grilles will be secured using the ladder ties strap provided. Use four per grille section.
7. Install grille shell back on truck. Reach in from the inside to install the push in fasteners.

TYPICAL CLIPPING INSTALLATION

