



# STREET SCENE EQUIPMENT, INC.

**950-77810 SATIN FINISH  
&  
950-78810 CHROME FINISH  
SPEED GRILLE  
1999 - 2000  
FORD RANGER  
2 WHEEL DRIVE ONLY**

## INSTALLATION INSTRUCTIONS

(note: For 4WD Use Part # 950-77815)

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
1	Upper Grille Section	1	Instruction Sheet	4	Long Attaching Clips #71099
1	Lower Grille Section	1	Street Scene Decal	12	Med. Attaching Clips # 71098
				1	Got Street Scene Decal

TOOL LIST
1/4" Socket & Ratchet

1. Open hood.
2. Remove the four 1/4" head screws securing the upper portion of the Grille Shell. Grasp the Grille Shell at the bottom edge and pull gently to release clips from support panel. **Note:** If metal clips are not retained on the Grille Shell, remove them from the grille support panel and install them on the Grille Shell before re-installing.
3. Set Grille Shell on a clean covered table or work bench. Remove Speed Grille inserts from their packages. Install the Speed Grille insert into the Grille Shell so that the face of insert is flush with the edge on the Grille Shell. Attach the lower grille insert using the 1 long clips in the center cavity use two on the top & two on the bottom. Attach the right & left sides using the med. long attaching clips. Use one at the top and one at the bottom. Attach the upper Speed Grille insert in the same manner using the med. long clips throughout. Install all clips with the flat side away from the grille insert. **Note:** Barbs on the clips should grab the inside of the hole on the Speed Grille insert.
4. Install Grille Shell back into vehicle by aligning the lower clips and gently tapping in. Install the four screws across the top.

