



STREET SCENE EQUIPMENT, INC.

950-76834 BLACK CHROME
950-77834 SATIN FINISH
950-78834 CHROME FINISH
2007-2008
FORD EXPEDITION
EDDIE BAUER MODEL
BUMPER COVER SPEED
GRILLE INSERTS

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Upper Speed Grille	1	Instruction Sheet	10	Installation Clips # 71098
1	Lower Speed Grille	1	Street Scene Emblem	1	Care For Grilles
				3	Push In Fasteners # 18379

TOOL LIST	
NO TOOLS REQUIRED	

1. Raise the front of vehicle to gain access to the bottom side of vehicle.
2. Disconnect the rubber air deflector from the metal crossmember by removing the three " push in " fasteners by prying them out. This will allow you to gain access to the back side of bumper.
3. Each Speed Grille section is labeled for a grille opening. Install one at a time from the front, then secure each section with five clips. The clips install from the back of the grille with the raised side facing inward.
4. The longer side of the Speed Grille section will face down. The Speed Grilles will attach at the bottom side only. The clips should be installed at the center and the outboard ends two or three inches from the ends. Install the remaining two clips between the center clip and the end clip.
5. Reconnect the rubber air deflector using the push in fasteners provided.