



STREET SCENE EQUIPMENT, INC.

950-77858
 950-78858
 2007
TOYOTA FJ CRUISER
MAIN GRILLE CHROME

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	8	Installation Clips # 71092
1	Care For Grilles	1	Street Scene Emblem		

TOOL LIST	
10 MM Socket, Ratchet	

1. Open hood.
2. Remove the two 10 MM head bolts securing the grille shell above the headlights.
3. Pry out the two push in fasteners located on the grille shell top.
4. Pull the bottom side of grille to " un-snap " the snap-in fasteners. Remove grille shell.
5. Install the Speed Grille over the diamond grids on the grille shell.
6. Flip over and install the eight installation clips with the " Humped " side facing the Speed Grille. Install clips as positioned in PHOTO BELOW.



Installation Clips
TYPICAL CLIPPING INSTALLATION

