



STREET SCENE EQUIPMENT, INC.

950-77859
950-78859
2007
TOYOTA FJ CRUISER
OEM VALANCE GRILLE
CHROME

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	8	Installation Clips # 71099
1	Care For Grilles	1	Street Scene Emblem		

TOOL LIST	
NO TOOLS NEEDED	

1. Set the Speed Grille insert over the opening in the front bumper.
2. From the back side secure the Speed Grille to the bumper cover using the eight clips provided. Use four on the top and four on the bottom sides. Refer to drawing below for clip installation.

TYPICAL CLIPPING INSTALLATION

