



STREET SCENE EQUIPMENT, INC.

950-77927 SATIN FINISH
950-78927 CHROME FINISH
2005 - 2007
CHEVY COLBALT
BUMPER
SPEED GRILLE INSERT

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Speed Grille Insert	1	Instruction Sheet	10	Installation Clips # 71099
1	Care For Grilles	1	Street Scene Emblem		

TOOL LIST	
NO TOOLS REQUIRED	

1. Install the Speed Grille insert into the lower opening. Attach using the ten installation clips provided. Use five clips on the top side and five on the bottom side. The drawing below will aid in the clip installation procedure.

TYPICAL CLIPPING PROCEDURE

