



STREET SCENE EQUIPMENT, INC.

950-80176
2007 - 2009
CHEVY SILVERADO
BILLET GRILLE
INSERTS

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Upper Billet Insert	1	Instruction Sheet	8	1/8" X 2" Toggle Bolts
1	Lower Billet Insert				

TOOL LIST	
Phillips Screwdriver	

1. Insert screw to the bracket on the grille, attach wing nut, thread it in 3 turns. Present it to the opening and line it up. Fold the wing nuts and push through the stock lined opening on vehicle.
2. Hold down wing nuts and start tightening the screws enough to hold the grille in place. (**DO NOT** over tighten.) Center the grille with equal spacing all around. Re-tighten screw if necessary.