



STREET SCENE EQUIPMENT, INC.

950-70109
1973 - 1987

ROLL PAN
GENERATION 1
FIBERGLASS

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See special instructions for paint Prep.) Parts that have been installed, prepped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

PARTS LIST					
1	Roll Pan	1	Instruction Sheet	1	Fiberglass Paint Prep Sheet
		1	Street Scene Decal	7	# 8 x 3/4" Washer Head Screws

TOOL LIST
Drill Motor, 5/32" Drill Bit, Masking Tape, Tape Measure, Phillips Screwdriver

1. Remove bumper and all attaching brackets.
2. Set the roll pan to body. Center roll pan by inserting a small piece of card board between each end of roll pan and body. Fold cardboard if necessary.
3. Align bottom side of roll pan and tape into position.
4. Open tail gate to full extend and check for clearance between tailgate and roll pan. Adjust roll pan as required.
5. Remove tailgate.
6. Drill five holes across the mounting flange of roll pan into the back of bed. Drill one hole in center and one two inches from each end and another centered between. If roll pan does not fit flush with bed you can install flat washers between bed and roll pan to shim.
7. Drill a hole in each lower corner through roll pan and into sheet metal. Install remaining screws.