



STREET SCENE EQUIPMENT, INC.

950-70122
FRONT VALANCE
99-2002 CHEVY SILVERADO
2000 - 04 CHEV TAHOE
&
SUBURBAN
GENERATION 3

INSTALLATION INSTRUCTIONS

NOTE: Fit all parts before painting (See Special Instructions For Paint Prep.) Parts that have been installed, preped, or painted are not returnable.

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

Note: Speed Grille part # 950-77122 for the valance openings is available as an option.

PARTS LIST					
1	Front Valance	1	Instruction Sheet	13	1/4-20 X 1" Bolts
26	1/4" Flat Washers	1	Street Scene Decal	13	1/4" Nyloc Nuts

TOOL LIST
7/16" Wrench, 7/16 Socket, Ratchet, Flat Blade Screwdriver, Safety Glasses, Drill Motor, 5/16" Drill Bit,

1. Before beginning installation be sure to wear proper eye protection.
2. Remove the stock valance and retaining clips by prying up with a flat blade screwdriver the center locking pin in the quick connect fastens and removing the 13 fasteners from valance. Remove valance and the female half of the fastener remaining on the bumper.
3. Set the factory valance on top of the Street Scene valance and mark the mounting hole location. Drill using a 5/16" drill bit.
4. Attach the valance to the bumper with the 1/4"-20 X 1" bolts provided. Use a flat washer on the top and bottom side. Do not tighten until all fasteners are installed and the valance is positioned against the bumper.